



compac

PREMIUM DISPENSER TECHNOLOGY

Laser Pump Installation Manual Version No 1.0.3

Model: Laser Pumps

Date: 7th December 2018



Conditions of Use

- Read this manual completely before working on, or making adjustments to, the Compac equipment
- Compac Industries Limited accepts no liability for personal injury or property damage resulting from working on or adjusting the equipment incorrectly or without authorization.
- Along with any warnings, instructions, and procedures in this manual, you should also observe any other common sense procedures that are generally applicable to equipment of this type.
- Failure to comply with any warnings, instructions, procedures, or any other common sense procedures may result in injury, equipment damage, property damage, or poor performance of the Compac equipment
- The major hazard involved with operating the Compac C4000 processor is electrical shock. This hazard can be avoided if you adhere to the procedures in this manual and exercise all due care.
- Compac Industries Limited accepts no liability for direct, indirect, incidental, special, or consequential damages resulting from failure to follow any warnings, instructions, and procedures in this manual, or any other common sense procedures generally applicable to equipment of this type. The foregoing limitation extends to damages to person or property caused by the Compac C4000 processor, or damages resulting from the inability to use the Compac C4000 processor, including loss of profits, loss of products, loss of power supply, the cost of arranging an alternative power supply, and loss of time, whether incurred by the user or their employees, the installer, the commissioner, a service technician, or any third party.
- Compac Industries Limited reserves the right to change the specifications of its products or the information in this manual without necessarily notifying its users.
- Variations in installation and operating conditions may affect the Compac C4000 processor's performance. Compac Industries Limited has no control over each installation's unique operating environment. Hence, Compac Industries Limited makes no representations or warranties concerning the performance of the Compac C4000 processor under the actual operating conditions prevailing at the installation. A technical expert of your choosing should validate all operating parameters for each application.
- Compac Industries Limited has made every effort to explain all servicing procedures, warnings, and safety precautions as clearly and completely as possible. However, due to the range of operating environments, it is not possible to anticipate every issue that may arise. This manual is intended to provide general guidance. For specific guidance and technical support, contact your authorised Compac supplier, using the contact details in the Product Identification section.
- Only parts supplied by or approved by Compac may be used and no unauthorised modifications to the hardware or software may be made. The use of non-approved parts or modifications will void all warranties and approvals. The use of non-approved parts or modifications may also constitute a safety hazard.
- Information in this manual shall not be deemed a warranty, representation, or guarantee. For warranty provisions applicable to the Compac C4000 processor, please refer to the warranty provided by the supplier.
- Unless otherwise noted, references to brand names, product names, or trademarks constitute the intellectual property of the owner thereof. Subject to your right to use the Compac C4000 processor, Compac does not convey any right, title, or interest in its intellectual property, including and without limitation, its patents, copyrights, and know-how.
- Every effort has been made to ensure the accuracy of this document. However, it may contain technical inaccuracies or typographical errors. Compac Industries Limited assumes no responsibility for and disclaims all liability of such inaccuracies, errors, or omissions in this publication.

Product Identification

Specifications

Models Covered

This manual applies to:

L40P
L80P
L80P Marine
L40PD
L40-80PD
LL40P
LL80P
LL40-80P
LL40PQ
L160P

NOTE: Do not use this manual for earlier models. Contact Compac for archived manuals if required.

Validity

Compac Industries Limited reserves the right to revise or change product specifications at any time. This publication describes the state of the product at the time of publication and may not reflect the product at all times in the past or in the future.

Manufactured By:

The Compac Laser Pump is designed and manufactured by Compac Industries Limited
52 Walls Road, Penrose, Auckland 1061, New Zealand
P.O. Box 12-417, Penrose, Auckland 1641, New Zealand
Phone: + 64 9 579 2094
Fax: + 64 9 579 0635
Email: techsupport@compac.co.nz
www.compac.biz
Copyright ©2015 Compac Industries Limited, All Rights Reserved

Product Identification



Document Control

| Document Information | |
|-----------------------------------|--------------------------------|
| Manual Title | Laser Pumps Installation Sheet |
| Current Revision Author(s) | R Liu |
| Original Publication Date | 24 June 2015 |
| Authorised By | W Zheng |
| File Name and Location | Laser Pump Installation Sheet |

| Revision History | | | |
|------------------|-------------|-----------|---|
| Version | Date | Author(s) | Revision Notes |
| 1.0.0 | 24 Jun 2015 | R Lacey | New Manual |
| 1.0.1 | 29 Aug 2016 | R Lacey | Corrected position of ID plate. Corrected COMS protocol |
| 1.0.2 | 11 Dec 2017 | S Laycock | Reformatted manual |
| 1.0.3 | 07 Dec 2018 | R Liu | Updated contact information |

Contents


| | |
|---|----|
| Product Identification | 3 |
| Footprints | 4 |
| L40P L80P L80P Marine | 4 |
| L40PD L40-80PD | 5 |
| LL40P LL80P LL40-80P | 6 |
| LL40PQ | 7 |
| L160P | 8 |
| Pump Flange and Optional Flexi Dimensions | 9 |
| Installation | 10 |
| Static Electricity Precautions | 10 |
| Pre-installation Check | 10 |
| Comms Dip-switch settings | 11 |
| Triac Dip-switches | 11 |
| Electrical Connections | 12 |
| Dispensing Hoses and Nozzles | 13 |
| Setting up the C4000 | 14 |
| Configuration Codes | 14 |
| Parameter Switch Settings | 14 |
| K-Factor Switch Settings | 15 |
| Calibration (K-Factor) | 16 |
| Standalone Operation | 17 |
| Notes | 18 |
| Pump Controller | 18 |
| Spare Fuses | 18 |
| Precautions if Using Generator Power | 18 |
| Error Messages | 19 |

Product Identification

Ensure you are using the correct installation instructions and footprint drawing before commencing site work or installation.

The identification plate is fastened to the bottom of the right-hand side panel when facing the front of the dispenser.

The model number is on the first line of the identification plate.



Understanding the model number:

The model number for Laser pumps is split into: Chassis style, hose configuration, pump or dispenser and specific application.

Use the table below to help identify the unit.

| Style | L/min per hose | Pump style | Options |
|--------------------|--|-------------------------------|-------------------------|
| L = single product | L40 = one hose @ 40 l/min | P = pump | Blank = 1 hose per pump |
| LL = two products | LL40 = two hoses @ 40 l/min | S = dispenser* | D=Dual - 2 hose 1 pump |
| | LL40-80 = side A 40 l/min, side B 80 l/min | *Dispensers have remote pumps | Q=Quad – 4 hose 2 pumps |
| | | | Marine = Marine |

For example: LL40P has two pumps with outlets on each end. L40PD has one pump with two outlets on one end and nozzle holders on the front and rear. LL 40PQ has two pumps and four hoses with two outlets at each end of the unit.

NOTE: Make sure you use the footprint that relates exactly to your model refer to sales order for any variations to the standard setup.

Footprints

Read the sales order to make sure the footprint matches the model number. There may also be variations to outlet position noted.

Outlets are approximately 680mm above the base. Check your sales order for possible variations.

Outlet size:

40 l/min 3/4" BSP female socket

80 l/min 1" BSP female socket

160 l/min 1 1/4" BSP female socket

L40P L80P L80P Marine




Figure 1: Footprints for L40P L80P L80P Marine

NOTE: For marine applications it is recommended that stainless steel pipework and fasteners are used.

L40PD L40-80PD






Figure 3: Footprints for L40PD L40-80PD

LL40P LL80P LL40-80P




LL40P LL80P LL40-80P

Figure 4: Footprints for LL40P LL80P LL40-80P





LL40PQ



LL40PQ

Figure 5: Footprints for LL40PQ

L160P



Footprint Plan View

L160P

Figure 6: L160P

Pump Flange and Optional Flexi Dimensions

Pump Flange




Figure 7: Pump Flange




Figure 8: Optional Flexi Coupling

NOTE: Flexi coupling is not suitable for marine use.

Installation

Static Electricity Precautions

Electronic components used are sensitive to static. Please take anti-static precautions.

An anti-static wrist strap should be worn and connected correctly when working on any electronic equipment. If an anti-static wrist strap is unavailable, or in an emergency, hold onto an earthed part of the pump/dispenser frame whilst working on the equipment. This is not a recommended alternative to wearing an anti-static wrist strap.

NOTE: *Compac Industries Limited reserves the right to refuse to accept any circuit boards returned, if proper anti-static precautions have not been taken.*

Pre-installation Check

Once the pump is received on site, check that no damage has occurred while in transit – in particular, damage to electronics due to vibration or jarring. All terminals and plugs should be checked, including IC chips, to ensure they are securely in place.




Figure 9: Installation Guidelines

Where local regulations require a sump to be fitted:

- a. Sumps must be provided at all dispenser installations with secondary containment pipework and at all new installations; and
- b. at all sites with sumps, dispensers should be installed with a liquid level detection device fitted in the sump that will raise an alarm if liquid is detected in the base of the sump.

DANGER: The pump inlet must not be pressurised at any time. This will cause fuel to flow from the air eliminator. Unregulated connection to an above ground tank will cause pressurisation.

DANGER: For above ground tanks a regulator valve such as a Tokheim valve or similar device **MUST** be used so that the inlet of the pump cannot become pressurised at any time.

CAUTION: The air switch is not to be disconnected. Disconnection will void NSC and TMU approvals.

Comms Dip-switch settings

The actual Comms I/O is controlled by the position of SW3.

| SW3 | Comms Protocol |
|------------|-----------------|
| Position 1 | Compac Standard |
| Position 2 | Gilbarco |
| Position 3 | RS485 |

Triac Dip-switches

It is very important that great care is taken not to accidentally change the setting of these switches while working in the Flame-proof box. Operating the unit with these incorrectly set can result in damage to the C4000 Power Supply or incorrect operation of the triacs.

These switches are set in the factory and should not be changed.

If they are accidentally changed these are the correct settings for Master / Premier Pump applications.

NOTE: They are 3 position switches

| Pump (Motor triac fitted) | |
|---------------------------|--------|
| SW1 | 1 |
| SW2 | 1 |
| SW4 | Centre |

Electrical Connections

The instructions below refer to basic installation wiring. For full wiring specifications refer to drawing AP375 available on the Resources section of the Compac website. Prior to pump installation ensure that there is at least a two-metre tail on both the incoming underground mains supply cable and comms cable (if comms enabled). These cables are terminated at the C4000 power supply, which is housed in the flameproof enclosure located in the bottom of the pump, behind the door.

Mains power wiring should be rated for a maximum current draw of 10 A rms at 220-240 V ac.

The incoming cables are terminated as shown in the following picture.


Refer to AS/NZS 60079.14 for appropriate cabling.

NOTE: All cables entering the power supply must be glanded with approved 20mm flameproof glands.

NOTE: Comms cable is not intrinsically safe.

NOTE: Pump comm's connect to pump controller such as DCA, Communicator Controller etc. (option).

When replacing the lid of the flameproof enclosure, ensure the sealing O ring is in place.



Dispensing Hoses and Nozzles

The unit may or may not be supplied with dispensing hose and nozzle assemblies.

If customer supplied hose assemblies, pylons, reels, safe breaks and nozzles are used they must comply with the requirements outlined in AS/NZS 2229.

Breakaways

For all dispensers fitted with breakaways, ensure the breakaway is installed between the nozzle and the high-mast or pylon (if fitted). Any breakaways that have been subject to a break-away situation should be inspected and refitted or replaced in accordance with the original manufacturer's instructions.

Setting up the C4000

Once the pump is connected on site, the final setup check and calibration to complete the installation must be carried out, using the Parameter Switch and Calibration (K-Factor) Switch.

These switches are found on the C4000 Microprocessor Board which is housed in a metal enclosure located on the left front of the unit below the display panel.

Configuration Codes

The configuration code has been set at Compac and should not be changed.

In the event of it being lost and having to be re-entered the configuration is written on the yellow label on the C4000 processor board cover.

Parameter Switch Settings

The parameter switch is used to configure the pump to your site.

Setting the Pump Number

This must be set at the pump for each hose, so that communications with a controller can take place. The location of this switch is shown in the diagram below.

Depress the Parameter Switch nine (9) or more times until the message **PnA **** appears in the litres display window. When the switch is pressed again **Pnb **** will appear on the display. These two options will toggle each time the switch is pressed. To alter either of the pump numbers, press and hold the Parameter Switch when the pump number to be altered appears on the display. This number will then increment. The switch should be released when the desired pump number is displayed. The value of the displayed number will then be stored in the C4000 memory as the pump number for that hose.

NOTE: For a single hose only **Pn** will appear

Setting the Price

Using the Parameter Switch, follow the chart to set the price for the hose(s) in question.

| Step | ACTION | RESULT |
|-------------------------------------|---|--|
| 1 | Ensure that the nozzle is hung up | Dispenser in idle state |
| 2 | Press and Hold the Parameter switch until the "Price per litre" is displayed. | The price for side A is shown as P**** on the litres display and P r A is displayed on the money display. |
| 3 | Press and hold the Parameter switch. | A digit, of the displayed 'Price per litre', will begin to increment. |
| 4 | When the digit is correct, release the Parameter switch. | |
| 5 | Repeat steps 3 and 4 for each digit of the 'Price per litre'. | NOTE: the C4000 will reset itself if the Parameter switch is left for more than 60 seconds. |
| Continue for Dual hose units | | |
| 6 | Press and release the Parameter switch 8 or more times in quick succession | The price for side b is shown as P**** on the litres display and P r b is displayed on the money display. |
| 7 | Repeat steps 3 to 5 above. | |

K-Factor Switch Settings

K-Factor, and other various configuration settings, are set via this switch. The position of the K-Factor switch is shown in the diagram below:




Figure 11: Location of K-Factor Switch

| | | |
|---------------------------------|---|------------------|
| J1: Comms Test | J7: Displays | J13: Not used |
| J2: To Power Supply | J8: Temperature (for Temperature compensation only) | J14: Not used |
| J3 : Input from KG Meter Side A | J 9 Power for KG Meters | J15: Not used |
| J4: Input from KG Meter Side B | J10: Totes | J16: Not used |
| J5 : Not Used | J11: Buzzer | J17 Backlighting |
| J6 Not used | J12 Nozzle Switches | |

Calibration (K-Factor)

Setting the K-Factor

K-Factor is a proportional calibration factor of litres dispensed per revolution of the meter.

To calibrate the dispenser/pump, dispense fuel into a certified measuring container, and compare the display value with the amount dispensed.

Example:

Display shows 10.00

True volume 20.00

To calculate the correct 'K' Factor from the information above; firstly record the existing 'K' Factor.

$$\begin{aligned}
 \text{New K Factor} &= \text{Existing K Factor} \times \frac{\text{Dispensed Amount}}{\text{Displayed Amount}} \\
 &= \text{Existing K Factor} \times \frac{20}{10} \\
 &= \text{Existing K Factor} \times 2
 \end{aligned}$$

Change the existing 'K' Factor to this new value.

Sealing the K-Factor switch

After calibration the K-factor switch should be sealed as shown:




Figure 12: Sealed K-Factor Switch

Standalone Operation

In standalone operation, the dispenser will continue working when not connected to a controller. '*Stand-alone*' mode being when no authorisation of fills is required and so fills are simply initiated by removing the refuelling assembly from its holder. If standalone operation is inhibited, the dispenser will not work in '*stand-alone*' mode, regardless of whether the dispenser is *ON LINE* to a controller or not.

The dispenser ceases to work in '*stand-alone*' mode if connected to a controller, regardless of the position of standalone setting.

Generally, on retail forecourts the dispenser should be set-up for standalone operation. Hence, if the forecourt controller breaks down the dispensers can be set to work in '*stand-alone*' mode simply by turning them off then on again.

For unattended refuelling sites, the dispensers should not be able to work in '*stand-alone*' mode in the event of a controller failure. Therefore, the dispenser should be set-up to inhibit standalone operation.

This is set in the **b** code on the K factor switch.

The **b** code to run Standalone without Dispenser Controller is **0000**.

The **b** code to inhibit Standalone is **1000**.

Notes

Pump Controller

If the pump is connected to a controller, check that pump data and transaction information is being correctly uploaded to it. Refer to the controller manual for specific instructions regarding connection and setup.

Spare Fuses

In the event of a fuse blowing on the C4000 Power supply a bag of 3 is included in each flameproof box. Any fuses used from this bag should be replaced.

NOTE: *There are three different ratings used. If replacing a fuse, ensure that the correct value is used.*

Precautions if Using Generator Power

The power output from onsite generators can cause power spikes that may damage electrical components within the cabinet. When connecting to sites powered by generators, please take the following precautions:

1. Install a power conditioner. Although generators are fitted with power regulators, most are not filtered sufficiently for powering sensitive electrical components. We recommend installing a commercial power conditioner and/or UPS between the generator and the unit.
2. Before starting a generator, make sure the power to the unit is turned off. Start the generator, let the generator reach stable operating speed and wait 30 seconds before reconnecting the power to the unit.
3. For units where the generator starts and stops on demand, install a delay timer or PLC to automatically isolate the unit until the operating speed and consistent power output is achieved.
4. Isolate the unit before shutting down the generator.

Error Messages

| Error Code | Fault | Action |
|------------|---------------------------------------|---|
| Err 3 | No price or pump number set. | Set the pump number or: Set a price at the pump or at the controller. |
| Err 7 | Excess flow. | Max Flowrate exceeded. |
| Err 8 | Excess reverse rotation of encoder. | Check product is not flowing back into the tank once the delivery has finished. |
| Err 9 | Faulty or disconnected meter encoder. | <ol style="list-style-type: none"> 1. Check that encoder is plugged in. 2. Replace encoder PCB on meter. |
| Err 10 | Configuration Lost. | Reconfigure C4000 refer to C4000 manual |
| Err 12 | C4000 memory failure. | Change memory IC. F-AD-DS1225 (not applicable to Futra.) |
| PEd Abd | Display error. | <ol style="list-style-type: none"> 1. Check display cable for loose wires/crimps. 2. Replace display PCB. |