



compac

INTEGRATED REFUELLING SOLUTIONS

Fillmaster Installation Manual Version 1.0.8

Model: C5000 Fillmaster

Date: 13th August 2020



Conditions of Use

- Read this manual completely before working on, or making adjustments to, the Compac equipment
- Compac Industries Limited accepts no liability for personal injury or property damage resulting from working on or adjusting the equipment incorrectly or without authorization.
- Along with any warnings, instructions, and procedures in this manual, you should also observe any other common sense procedures that are generally applicable to equipment of this type.
- Failure to comply with any warnings, instructions, procedures, or any other common sense procedures may result in injury, equipment damage, property damage, or poor performance of the Compac equipment
- The major hazard involved with operating the Compac C5000 processor is electrical shock. This hazard can be avoided if you adhere to the procedures in this manual and exercise all due care.
- Compac Industries Limited accepts no liability for direct, indirect, incidental, special, or consequential damages resulting from failure to follow any warnings, instructions, and procedures in this manual, or any other common sense procedures generally applicable to equipment of this type. The foregoing limitation extends to damages to person or property caused by the Compac C5000 processor, or damages resulting from the inability to use the Compac C5000 processor, including loss of profits, loss of products, loss of power supply, the cost of arranging an alternative power supply, and loss of time, whether incurred by the user or their employees, the installer, the commissioner, a service technician, or any third party.
- Compac Industries Limited reserves the right to change the specifications of its products or the information in this manual without necessarily notifying its users.
- Variations in installation and operating conditions may affect the Compac C5000 processor's performance. Compac Industries Limited has no control over each installation's unique operating environment. Hence, Compac Industries Limited makes no representations or warranties concerning the performance of the Compac C5000 processor under the actual operating conditions prevailing at the installation. A technical expert of your choosing should validate all operating parameters for each application.
- Compac Industries Limited has made every effort to explain all servicing procedures, warnings, and safety precautions as clearly and completely as possible. However, due to the range of operating environments, it is not possible to anticipate every issue that may arise. This manual is intended to provide general guidance. For specific guidance and technical support, contact your authorised Compac supplier, using the contact details in the Product Identification section.
- Only parts supplied by or approved by Compac may be used and no unauthorised modifications to the hardware or software may be made. The use of non-approved parts or modifications will void all warranties and approvals. The use of non-approved parts or modifications may also constitute a safety hazard.
- Information in this manual shall not be deemed a warranty, representation, or guarantee. For warranty provisions applicable to the Compac C5000 processor, please refer to the warranty provided by the supplier.
- Unless otherwise noted, references to brand names, product names, or trademarks constitute the intellectual property of the owner thereof. Subject to your right to use the Compac C5000 processor, Compac does not convey any right, title, or interest in its intellectual property, including and without limitation, its patents, copyrights, and know-how.
- Every effort has been made to ensure the accuracy of this document. However, it may contain technical inaccuracies or typographical errors. Compac Industries Limited assumes no responsibility for and disclaims all liability of such inaccuracies, errors, or omissions in this publication.

Product Identification

Specifications

Models Covered

This manual applies to the Fillmaster

NOTE: Do not use this manual for earlier models. Contact Compac for archived manuals if required.

Validity

Compac Industries Limited reserves the right to revise or change product specifications at any time. This publication describes the state of the product at the time of publication and may not reflect the product at all times in the past or in the future.

Manufactured By:

The Compac Fillmaster is designed and manufactured by Compac Industries Limited

52 Walls Road, Penrose, Auckland 1061, New Zealand

P.O. Box 12-417, Penrose, Auckland 1641, New Zealand

Phone: + 64 9 579 2094

Fax: + 64 9 579 0635

Email: techsupport@compac.co.nz

www.compac.biz

Copyright ©2015 Compac Industries Limited, All Rights Reserved

Document Control

Document Information	
Manual Title	Fillmaster Installation Manual
Current Revision Author(s)	V Amarakoon
Original Publication Date	17 May 2018
Authorised By	W Zheng

Revision History			
Version	Date	Author(s)	Revision Notes
Lite	17/05/18	S Laycock	Initial draft
1.0.0	22/06/2018	S Laycock	Added mechanical installation instructions and footprints.
1.0.1	09/07/2018	S Laycock	Added relay wiring, revised software section, added sim card installation instructions. Added additional footprints.
1.0.2	25/07/2018	S Laycock	Updated CompacOnsite section
1.0.3	24/08/2018	S Laycock	Updated CompacOnsite and external pump wiring
1.0.4	07/12/2018	R Liu	Updated contact information
1.0.5	20/01/2020	V Amarakoon	Updated footprints
1.0.6	17/07/2020	V Amarakoon	Updated Software setup (new menu layout) Updated Installation Added above ground tank installation
1.0.7	04/08/2020	V Amarakoon	Added MMR400-160S Footprint
1.0.8	13/08/2020	V Amarakoon	Added MR400S Footprints

Contents

Footprints	1
Optional Flexi Coupling	1
MMR40P MMR80P MMR80-40P	2
MR40P MR80P	3
MR160P	4
MR80S & MR40S	5
MR160S	6
MR400S (Includes "Marine" variants)	7
MR400S Aviation	8
MMR160S	9
MMR40S MMR80S MMR80-40S	10
MMR160-80S & MMR160-40S(Includes "Marine" variants)	11
MMR400-160S (Includes Marine & Aviation variants)	12
Installation	13
Static Electricity Precautions	13
Pre-installation Check	13
Procedures	13
Dispensing Hoses and Nozzles	16
Electrical	17
Software	21
System	21
Pumps	21
Cards and Card Users	22
Meters	23
Tanks	23
Software Setup	24
CompacOnsite	27
Users	28
Technician Options	28
Administrator Options	35
Standard User Options	37
Events	38
Error Codes	42
Installation Checklist	43

Footprints


All outlets are approximately 680mm above the base:

- 40 l/min - 3/4" female BSP socket
- 80 l/min - 1" female BSP socket
- 160 l/min - 1 1/4" female BSP socket


Inlet pipework can be connected to the pump flange(s). An optional flexible coupling is offered by Compac. There must be no fuel pressure in the pump line when pump is not operating.

NOTE: For some of the following footprints, the C5000 junction box may be mounted in a different position. This does not affect the dimensions or inlets but is important when bringing cables in.

Optional Flexi Coupling



MMR40P MMR80P MMR80-40P




* **NOTE:** For a "MMR40P" unit a 1" BSP Male to 3/4" BSP Female Reducer is fitted to both outlets.

* **NOTE:** For a "MMR80-40P" unit a 1" BSP Male to 3/4" BSP Female Reducer is fitted to one outlet.

MR40P MR80P


C5000 K-Factor Board is located in the "Front" Display Enclosure




C5000 Junction Box. Bring incoming Mains & Comms cables into here.

Front View

Contractor to supply & install pipework to connect to this flange.



Rear of Unit



Front of Unit


Footprint Plan View

"3 bolt" Triangular Pump Flange

* **NOTE:** For a "MR40P" unit a 1" BSP Male to $\frac{3}{4}$ " BSP Female Reducer is fitted to the outlet.

MR160P


C5000 K-Factor Board is located in the "Front" Display Enclosure




C5000 Junction Box. Bring incoming Mains & Comms cables into here.

Front View

Contractor to supply & install pipework to connect to the two "supplied" "Non-return" Valves.



Rear of Unit




Front of Unit Footprint Plan View

"3 bolt" Non-return Valve (to be fitted to each Pump Inlet Flange)

MR80S & MR40S

C5000 K-Factor Board is located in the "Front" Display Enclosure





C5000 Junction Box. Bring incoming Mains & Comms cables into here.

Front View

Contractor to supply & install pipework to connect to this 1" BSP Female Inlet Socket.

Rear of Unit




Front of Unit

Footprint Plan View

* **NOTE:** For a "MR40S" unit a 1" BSP Male to $\frac{3}{4}$ " BSP Female Reducer is fitted to the Outlet.

MR160S

C5000 K-Factor Board is located in the "Front" Display Enclosure





C5000 Junction Box. Bring incoming Mains & Comms cables into here.

Front View

Contractor to supply & install pipework to connect to this 1 1/2" BSP Female Inlet Socket. (Behind Junction Box in this view)

Rear of Unit





Front of Unit

Footprint Plan View

MR400S (Includes "Marine" variants)

**** NOTE:** Contractor to supply and install pipework to suit one of the two available "Inlet Option" types, depending on which of the two options applies to an Installation.



IMPORTANT: The "Y-Strainer" fitted to the Inlet of the Dispenser does not protect the Meter & Solenoid Valve/s from "fine" particles.



MR400S Aviation


**** NOTE:** Contractor to supply and install pipework to suit one of the two available "Inlet Option" types, depending on which of the two options applies to an Installation.

IMPORTANT: The "Y-Strainer" fitted to the Inlet of the Dispenser does not protect the Meter & Solenoid Valve/s f



MMR160S

C5000 K-Factor Board is located in the "Front-left" Display Enclosure





Front View

C5000 Junction Box. Bring incoming Mains & Comms cables into here.

Contractor to supply & install pipework to connect to these two 1 1/2" BSP Female Inlet Sockets. ("Side A" Behind Junction Box in this view)

Rear of Unit



Front of Unit

Footprint Plan View

MMR40S MMR80S MMR80-40S

C5000 K-Factor Board is located in the "Front-left" Display Enclosure

Side B
Nozzle Holder


Side A
Nozzle Holder

Side B
Outlet:
1" BSP
Female
thread *

Side A
Outlet:
1" BSP Female
thread *

Triangular Slip
Flanges (can be
rotated to any
orientation)

Triangular
Flanges with
1" BSP Sockets
are removable.



Front View

C5000 Junction Box. Bring incoming Mains & Comms cables into here.

Contractor to supply & install pipework to connect to these two 1" BSP Female Inlet Sockets.


Rear of Unit

Side B
1" BSP Female
Inlet Socket on
rotatable
triangular flange.

(6x) Mounting
Holes $\varnothing 20$


Side A
Outlet

Side A
1" BSP Female
Inlet Socket on
rotatable
triangular flange.



Front of Unit

Footprint Plan View





Footprints

* **NOTE:** For a "MMR40P" unit a 1" BSP Male to 3/4" BSP Female Reducer is fitted to both Outlets.

* **NOTE:** For a "MMR80-40P" unit a 1" BSP Male to 3/4" BSP Female Reducer is fitted to one Outlet.

MMR160-80S & MMR160-40S (Includes "Marine" variants)

C5000 K-Factor Board is located in the "Front-left" Display Enclosure




C5000 Junction Box. Bring incoming Mains & Comms cables into here.

Front View

Contractor to supply & install pipework to connect to this 1 1/2" BSP Female Inlet Socket & this 1" Female Inlet Socket.

Rear of Unit



Footprint Plan View **


* **NOTE:** For a "MMR160-40S" unit a 1" BSP Male to 3/4" BSP Female Reducer is fitted to this Outlet.

** **NOTE:** The footprint will be rotated 180° on a unit that has the Hoses "reversed".

MMR400-160S (Includes Marine & Aviation variants)

**** NOTE:** Contractor to supply and install pipework to suit one of the two available "Inlet Option" types, depending on which of the two options applies to an Installation.


IMPORTANT: The "Y-Strainer" fitted to the "400lpm Inlet" of the Dispenser does not protect the Meter & Solenoid Valve/s from "fine" particles.



Side A (400lpm) Inlet:

2" BSP Female thread on the Y-Strainer (without Dual Inlet Manifold) **or** 1 1/2" BSP Male thread (with Dual Inlet Manifold)

Rear of Unit



Installation

Static Electricity Precautions

Electronic components used are sensitive to static electricity. Please take anti-static precautions.

An anti-static wrist strap should be worn and connected correctly when working on any electronic equipment. If an anti-static wrist strap is unavailable, or in an emergency, hold onto an earthed part of the pump/dispenser frame whilst working on the equipment. This is not a recommended alternative to wearing an anti-static wrist strap.

NOTE: *Compac Industries Limited reserves the right to refuse to accept any circuit boards returned, if proper anti-static precautions have not been taken.*

Pre-installation Check

Once the pump is received on site, check that no damage has occurred while in transit – in particular, damage to electronics due to vibration or jarring. All terminals and plugs should be checked, including IC chips, to ensure they are securely in place.

Procedures

Installation should be in accordance with local regulations.

To obtain maximum flow on a self-contained pump, observe the following guidelines:

Below Ground Tank Installations


1. Pumps must not be subject to any head pressure. Design your installation to eliminate any possibility of this occurring.
2. Total length of horizontal piping between tank and pump should be no longer than 18 metres. Use galvanised steel or approved non-metallic pipe and fittings.
3. If the unit contains two pumps. It is recommended that each pump is supplied by a separate pipe. The common sizes used are.
 - 40 l/min pumps, use 1½" pipe
 - 80 l/min- 160l/min pumps, use 2" pipe.
 - 400l/min pump use 3" pipe.
4. Check valves must also be installed below each pump inlet.
5. On 160lpm units, if a single 3" Suction line is used, Check valves must be fitted to the inlets of both pumps to prevent one pump drawing product back through the other.

NOTE: *Ensure you remove the bung from the pump inlet before connecting the pipe.*

6. Pipe must slope up from the tank to the pump (approximately 15 mm per metre). Pipe should be straight and supported along its length.
7. All horizontal piping must be buried at least 450mm below ground level.

8. The area under the pumping unit(s) must be filled with sand or dirt as far up the suction line as possible. Use water to pack the sand or dirt when put in place.
9. Avoid asphalt drive surfaces covering the piping. Asphalt increases heat absorption causing vapour lock.
10. Static lift must not exceed 3 metres (vertical distance from the product level in the tank to the centre of the pump unit).
11. To absorb ground movement from settling of the tank, frost heaving of the ground or pump island settling, a swing joint must be used in the supply line at the tank and directly underneath the dispenser. Three additional directional changes using elbows are permitted.
12. Piping must hold a 3.4 Bar (50PSI) pressure test for a minimum of 10 minutes.
13. It is recommended that a vertical, in-line check valve be installed underneath the pump.
14. The dispensing equipment shall be installed to prevent the delivery hose from contacting the ground when not in use.
15. A check valve must be installed at the tank end connection of the suction pipe in a serviceable location. Many clients install an extra check valve at the inlet to the pump. It is important neither of the check valves interfere with the flow of fuel. They must be adequately sized.

Refer to the footprint drawings for pump installation details.



Above Ground Tank Installations

If a regulator valve is not installed correctly product will pour out of the pump breather. If this happens, do not plug the breather. Review the installation and ensure that all the following requirements have been met.

The regulator valve must be mounted in the vertical position and directly underneath the pump. Do not mount alongside the pump as no pipework between the regulator valve and the pump is allowed to be below the regulator valve itself.

Do not plug the vent on the regulator valve. Pipe the vent back to the top of the tank or vent to atmosphere.


Maximum working pressure of fuel system = 50 psi / 3.4 bar

The installation must include a thermal expansion relief valve. Thermal expansion can cause pressures in the system greater than 50 psi / 3.4 bar and can result in failure of the valve and loss of product to the environment.

The installation must also include a solenoid valve positioned adjacent to the shut off valve at the tank. Its purpose is to prevent loss due to failure of the downstream piping or the system. The recommended solenoid is the Parker 2" type E321G4010 (available from Compac)

The Shear section of the regulator valve should be located level with the bottom of the cabinet base.

The installation must include a shutoff or gate valve to close the system and prevent loss when the equipment utilized in the fuelling system downstream from the above ground storage tank is being serviced or replaced.



Above Ground

Where local regulations require a sump to be fitted:

- a. Sumps must be provided at all dispenser installations with secondary containment pipework and at all new installations.
- b. At all sites with sumps, dispensers should be installed with a liquid level detection device fitted in the sump that will raise an alarm if liquid is detected in the base of the sump.

DANGER: The pump inlet must not be pressurised at any time. This will cause fuel to flow from the air eliminator. Unregulated connection to an above ground tank will cause pressurisation.

DANGER: For above ground tanks a regulator valve such as a Tokheim valve or similar device **MUST** be used so that the inlet of the pump cannot become pressurised at any time.

CAUTION: The air switch is not to be disconnected. Disconnection will void NMI and TMU approvals.

CAUTION: When a 52a valve is installed at the pump, never install a vacuum anti-syphon valve at the top of the tank. An electric solenoid valve is required

Dispensing Hoses and Nozzles

The unit may or may not be supplied with dispensing hose and nozzle assemblies.

If customer supplied hose assemblies, pylons, reels, safe breaks and nozzles are used they must comply with the requirements outlined in AS/NZS 2229.

Breakaways

For all dispensers fitted with breakaways, ensure the breakaway is installed between the nozzle and the high-mast or pylon (if fitted). Any breakaways that have been subject to a break-away situation should be inspected and refitted or replaced in accordance with the original manufacturer's instructions.

Glanding

All gland holes into the flameproof box are standard M20 x 1.5 gland threads.


Electrical

When installing the Fillmaster, internal wiring will be pre-connected. External wiring will need to be connected to the K-Factor board and the Terminal Board.


Terminal Board

The terminal board can be located inside the flame-proof box of the C5000, on the top layer of the power supply. The incoming mains will be wired into the terminal board. The incoming mains wiring is as follows. An emergency stop connection, if desired, can be wired into the terminal board wiring, shown below. This will be in place of the normal loop between the triac and main phases. Wires have standard colours which are shown. In case these are unclear, the colours are as follows:

- Incoming mains phase: Brown
- Incoming mains neutral: Blue
- Incoming mains earth: Green/Yellow




The external pump connections are as shown. Wire in the required side(s).



Installation

K-Factor Board

The K-Factor board is located behind the display under the black cover. The nozzle switch, sump, air switch, and meter should be connected to the K-Factor board. These connections are as shown. The K-Factor board has connections for both side A and side B. Current Fillmaster are operable with side A only. The K-Factor switch should be sealed for security. Optional mechanical totes can also be connected to the K-Factor board, which increment mechanically with each litre of fuel dispensed.



Bus out system cables - can connect slave display to here

Connect optional mechanical totes to here


Side A Connections

Connect Sump Switch to here

Connect Air Switch to here


Connect Nozzle Switch to here

Connect Meter to here




Installing the Sim Card

To install the sim card, the modem needs to be removed. The location of the modem is as shown:



As shown, there is a small plastic panel on the back of the modem. This can be removed. The supplied sim card should be installed under this panel. The panel and modem should then be replaced.



Software

This section details what options are available for the unit and what each setting means. Some settings may not be available for each specific unit.

System

Card Records

Before cards can be added, card records need to be set up from the unit. When setting up card records, a PAN length, BIN range, and access number can be specified. These are encoded onto the card and can be used to restrict access to the pumps. PAN length is the number of digits that make up the BIN number and card number. The BIN range gives access to a range of cards that have similar BIN numbers. BIN numbers are always 6 digits long. To make this into a BIN range, two numbers must be added. For example, if a card had the following card number:

7824331000132017

The card is 16 digits long, therefore the PAN length is 16.

The BIN number is 782433. To allow all cards with the same BIN number access:

BIN low should be set to 78243300.
BIN high should be set to 78243399.

This would allow all cards with a BIN number of 782433 access. The Access number is used to further restrict cards. This is a 5-digit number and will be encoded onto the cards. 0 should be entered into the Access field if the card does not have an access number. Once the card records are set up, specific cards can be entered into the system using PAN numbers.

If a card is hotlisted, it will be accepted even if the card PAN number has not been entered. Otherwise, the card's individual PAN number will have to be entered as a card. Prompts are an optional setting which may be chosen when setting card records. The prompts that are selected when entering a card will appear when that card is swiped; for example, if odometer is selected, the card holder will have to enter an odometer number to access the fuel pump. Cards can be enabled or disabled.

Passcode

For security, the unit has a passcode. This can be used to access settings from the unit. For extra security, if the settings are accessed with the passcode, some options are not able to be changed, such as the K-Factor setting. These must be accessed by pressing the K-Factor switch.

The unit supports three different authorisation modes: PIN, HID or Cardreader. The system can be set up from either CompacOnsite or from the unit itself.

Pumps

The Fillmaster supports two configurations, single and dual, enabling two pumps to be used simultaneously if one card is used. These pumps are assigned a side so that they may be individually customised. Each side must be numbered between 1-99.

NOTE: Entering a pump number 0 will disable the pump.

Individual settings for each pump include the fuel product used, which has a name and product code, and the meter used at each pump. The unit supports encoder meters (max frequency 3.5Khz) or V50 meters. The K-Factor, used to calibrate fuel flow, can also be set for each pump. The state of the pumps can be either operational or locked, which may be desired if the pump is not operating normally. Pumps have two solenoids for product flow. If the solenoids are unavailable, the pump preset should also be unavailable. Solenoid delay, the amount of time it takes the solenoids to turn on after lifting the nozzle, can be customised for each side. Auto authorisation can be enabled for a pump, allowing the pump to be authorised without lifting up the nozzle.

Preset Cut-off and Rounding

Preset cut off is used to deliver an accurate amount of fuel. When dispensing fuel, two solenoids are used for fuel flow. When the dispensed amount of product reaches the preset cut off, one solenoid is turned off to slow delivery rate and dispense an accurate volume of product.

A two-digit number can be assigned to determine the preset rounding in litres. The first digit determines how the preset is rounded down, and the second digit determines how the preset is rounded up. For example, if Preset Rounding is set to 89 and the preset is 40;

40.08 is within .08 of 40 and would therefore be rounded down to 40.

39.91 is within .09 of 40 and would therefore be rounded up to 40.

Flow Range

A flow range is needed for each pump to dispense an accurate amount of product. If too much or too little fuel is dispensed, the meter cannot accurately measure the dispensed fuel and therefore should cut off and display an end of sale message. The flow range will vary for different products. Flow low should be the lower value of the flow range, while Flow high is the highest possible flow.

NOTE: Flow range is optional. The default value is 0.

A flow timeout can be set, which cuts off the motor after the set amount of time. The default is 000, which is 20 seconds.

Unit Price and End of Sale

The unit price is the price per litre of fuel dispensed. For this unit, it is displayed in the Card Totals window.

End of sale indicators show why the motor stopped during the last sale.

Cards and Card Users

Card numbers must be added for a card to be valid. Card or HID numbers can be added. These numbers should correlate to the earlier card setup done in the system section.

Cards can also have User IDs, which are optional prompts for cards. If a User ID is asked for the customer dispensing fuel will have to enter a valid User ID. If a user ID is not required, and instead the retailer wants a different prompt (such as Fleet number) user ID can be configured to ask for different prompts.

Meters

The unit supports encoder or V50 Modbus meters. The encoder meters can be single, dual or triple channel. Single channel encoders measure the fuel dispensed. Dual channel encoders do this as well as determine the rotation of the meter (and therefore the direction of fuel flow). Triple channel meters can determine if the meter is correctly connected and functioning.

K-Factor

The K-Factor is used to calibrate product flow. It is a ratio of litres dispensed per revolution of the meter. The K-Factor may need to be calibrated after periods of time. To calibrate the pump, dispense fuel into a certified measuring container and compare the display value with the one dispensed.

Example:

Display shows 10.00 True volume 20.00

To calculate the correct K-Factor from the information above; firstly record the existing K-Factor.

$$\begin{aligned} \text{New K Factor} &= \text{Existing K Factor} * \frac{\text{Dispensed Amount}}{\text{Displayed Amount}} \\ &= \text{Existing K Factor} * \frac{20}{10} \\ &= \text{Existing K Factor} * 2 \end{aligned}$$

Unique ID is for a V50 meter only.

Once the K-Factor has been determined, refer to Setup Instructions (see page 25) for instructions on how to change the K-Factor,

Tanks


Tanks can be set up with their corresponding product, number and capacity.

Tank Gauging


Tank gauging is used to determine how much fuel is left in a tank. The Fillmaster supports four tank gauges; Veeder-Root, Fafnir, Vega and Virtual. To accurately gauge the volume of fuel, the tank number, safe fill level and capacity are required. These depend on the tanks onsite. If a Vega electronic dipstick is used, please note that more information will be required; the position of the probe in the tank is needed. A Tank Strapping table ID will be required to calculate volume. A Vega electronic dipstick may also be connected differently; the gauge channel may change depending on the connection to the Comms board.

Software Setup

To change settings from the unit you must either have access to the K-Factor switch, which is located on the inside of the unit on the K-Factor board, or have the passcode to the unit.



Pressing the K-Factor switch will bring up a menu displaying set up options on the Keypad display. The available options are shown below. The same menu can be accessed by pressing Cancel on the standard display and entering the passcode.



IMPORTANT NOTE: The settings shown on each individual unit will depend on the current software version. Not all the options shown here may be displayed on every unit.

NOTE: If the menu is accessed by entering the passcode, not all the settings will be available. K-Factor and meter setup can only be accessed by pressing the K-Factor switch.

The K-Factor switch must be sealed after servicing.

NOTE: The system has a timeout of 15 seconds.

Some software setup options are not shown here. Instead, only options which are required to set up the unit are explained. Refer to the Fillmaster Service Manual for a full list of software set up instructions.

Setup Instructions

To set up the site, first set up the available products.

1. Go to Products
2. Select a product number and enter an available product

```

MENU
1.PRD #01      NOT SET
2.PRD #02      NOT SET
3.PRD #03      NOT SET
4.PRD #04      NOT SET
5.PRD #05      NOT SET
                Next(<#>)
  
```

Once products have been set, the site tanks can be set up. Select TANKS from the main menu and select TANK A or TANK B.

```

TANK A
1.TYPE          NONE
2.ENABLED      DISABLED
3.TANK #        00
4.PRODUCT
5.CAPACITY     00000000
                Next(<#>)
  
```

```

TANK A 2
1.SFL          00000000
                (<*)PREV
  
```

1. The tank gauge type can be changed by selecting 1. The options are VDR, Vega, Virtual, Fafnir.
2. Tank gauging can be enabled or disabled by pressing 2.
3. The tank number and capacity can be set by selecting the desired functionality and entering the new value.
4. The product can be set by pressing 4 and selecting an established product.

Safe fill level can be changed by pressing 1 and entering the new value in litres.

Now the site tanks have been set up. Next, the pumps should be configured for the unit. To do this:

1. Go to Pumps > Select the relevant pump
2. To allow the pump to be used, first set a pump number between 00 and 99
3. Select the product that will be used at the pump
4. Enable the pump
5. Used the (#) key to scroll for more options. Ensure the unit price is correct

```

SIDE A CONFIG 1
1.NUMBER        05
2.PRODUCT       UNLEADED
3.ENABLED       ENABLED
4.INFO          IDLE
5.METER
                Next(<#>)
  
```

```

SIDE A CONFIG 2
1.FLOW
2.PRESET
3.MODE
4.COMMS
5.ADVANCED
                (<*)PREV
  
```

All other options for pumps are optional or have default values. If these optional settings are desired, the pump can be customised. Refer to Software for information on these options. To change these settings, simply scroll between options using the (#) and (*) keys. Select the desired setting and enter the desired value. The Fillmaster Service Manual gives full instructions on changing each setting.

Next, the meter should be set up. To set up the meter:

1. Select PUMPS from the main menu, select pump number and then select METER will bring up the following menu.

SIDE A METER CONFIG	
1.TYPE	3CH ENC
2.K FACTOR	005.0000
3.UNIQ ID	N/A
4.CALIB	DISABLED

2. Ensure the correct meter is selected. Fillmaster currently only has 3 channel encoder, so this should be selected
3. Ensure the K-Factor is correct. Refer to software for instructions on how to calibrate the K-Factor

The unit is now operational. For further settings and customisation of the unit refer to the service manual supplied with the unit.

Finding the Device ID

The device ID is required to log on to CompacOnsite. If this is not known, it can be found by selecting SYSTEM from the main menu and then select DEVICE.

DEVICE ID
CFM000000
.compaconsite.com

CompacOnsite

The unit can be set up online via CompacOnsite. To access CompacOnsite, the device ID is needed. The following should be entered into an internet browser, replacing device ID with the specific ID of the unit. Refer to Software Setup for instructions on finding the Device ID.

<https://deviceID.compaconsite.com>

The standard passwords are shown below.

IMPORTANT NOTES:


For the security of the site, ensure the passwords are changed once the unit is installed.

Access to online data is heavily dependant on the unit being powered on and connected to the internet. Ensure the unit is online in order to have full access to all site data.

Username	Password
user	c0mpac5KUser
admin	c0mpac5KAdmin
tech	c0mpac5KTech

After log in, the CompacOnsite home screen will appear.

NOTE: The side bar will look different depending on the access level of the user.



Users


There are three different user options when logging into Compac Onsite; standard, technician and administrator. Each user can access different functionalities. Standard users can access all basic functionalities, such as tanks, cards and transactions. Admin users can also access these, as well as being able to access the system settings and reboot. The technician can access all these options, as well as being able to access set up options which are needed when setting up the site.

Technician Options

Technician users can access both administrator and standard user options. As well as this, they can access site setup options.

Dispenser Setup

Dispenser Setup will bring up a setup menu with four options; Products, Pumps, Tank Gauging and Tank Strapping.



In the Products tab, the current products can be viewed.

To create a product, Add Product can be selected. The product must be named and numbered before it can be saved. The following menu will appear.

Create Product

Product Code:

Product Name:

Pressing Submit will add the product. When a product is edited the same menu will appear, and the product's name and number can be changed before resubmitting.

To delete a product, select the recycle bin icon in the products table, and click OK on the pop-up.

The next tab is the Pumps tab. From this tab, the configuration of the unit (single or dual) can be chosen, as well as the settings for each pump.

Setup

Products
Pumps
Tank Gauging
Tank Strapping

Pumps

Side A

Pump number (1-98)	<input style="width: 80%; padding: 5px;" type="text" value="0"/>
Product	<input style="width: 80%; padding: 5px;" type="text"/>
Meter type	<input style="width: 80%; padding: 5px;" type="text"/>
State	<input style="width: 80%; padding: 5px;" type="text" value="Disabled"/>

Depending on the chosen configuration, only one side may be displayed.

To change the Pump number simply enter the new value and press Update.

To change the product, meter type or state, select the relevant option from the drop down menus and press update.

The Tank Gauging tab shows which tank gauge is selected for each tank.

Setup

Products Pumps **Tank Gauging** Tank Strapping

Tank Gauging

Enabled	Gauge Type	Product	Capacity (L)	Safe Fill Lev...	Gauge C...	Tank Num...	
✘			0	0	0	0	Edit
✘			0	0	0	0	Edit

The current settings can be viewed. To edit a row, select Edit.

Edit Tank Gauge Settings

Gauge Type

Product

Tank Number

Tank Capacity (L)

Safe Fill Level (L)

Enabled

To change a setting, enter the new setting and Submit the new values.

If a Vega tank gauge is being used, more information is required. The required fields will automatically appear if a Vega meter is selected.

Edit Tank Gauge Settings

Gauge Type

Tank Strapping Table ID

Distance from probe to product for full tank (mm)

Distance from probe to tank bottom (mm)

Tank Gauge Channel

Product


Tank Number

Tank Capacity (L)

Safe Fill Level (L)

Enabled

The final tab in Dispenser Setup is the Tank Strapping section. This section is only relevant if a Vega meter is fitted. Refer to Vega Tank Strapping for information.



To download the tank strapping table, select download current strapping table. At the bottom of the page, tables can be uploaded and the table template can be downloaded. Use the table ID drop down menu to select the table ID.

FMS Setup

When setting up the unit, the FMS setup tab can be used to set up card records.

FMS Settings

Card Prefix Table

Name	Enabled	BIN high	BIN low			

Name:

BIN high:

BIN low:

Access:

PAN length:

Hotlist

Expiry check

Prompts

Preset

PIN

Odometer

User ID

Enabled

Cards can be imported and exported as .csv files. This option can be found in this tab. To add a new card, fill in the required fields and check which prompts are desired. Checking Enabled will enable the card. When the card is finished, press Submit. Current cards can be viewed in the Card Prefix Table.

Administrator Options

Administrators can access all the above options, as well as being able to access pricing, settings and reboot.

Pricing

From pricing, the pricing for different products can be viewed and changed.

Pricing

Product Prices

Product ▲	Product Code ▲	Active Price ▲	New Price ▲	
ULP	2	2.500	2.500	Set New Price
Diesel	3	1.310	1.310	Set New Price

Price Change

Apply new product prices. This will change prices on pumps.

Note: For commercial variants, price changes only apply to external pumps.

[Use New Prices](#)

The Active Price is the price being used currently for the pumps. To change this, select Set New Price.

Set New Price

Product Name:

ULP

New Price:


2.500

[Change Price](#)

Enter the new price for any product and select Change Price. This will change the New Price. However, the unit will continue to use the Active Price until Use New Prices is selected, under Price Change. Clicking this will change the Active Price and update them to the New Price.

Settings

Settings can be used to set site details. Enter the site details and press submit.



The screenshot shows a web form with two main sections: "Site Details" and "Time".

Site Details

- Site Name:** A text input field with the placeholder "Enter new site name".
- Site Address 1:** A text input field.
- Site Address 2:** A text input field.
- Site Address 3:** A text input field.
- Site Address 4:** A text input field.
- A "Submit" button.

Time

- Timezone:** A dropdown menu showing "(UTC+12:00) Auckland, Wellington".
- Daylight Saving Time
- A "Submit" button.

Timezone can also be set. In some cases, timezone will be automatically synced. Enter the timezone and press submit.

Reboot

Reboot is used to restart the application. Some settings require rebooting to update recent actions. The page needs to be refreshed after the Reboot process has been completed.

NOTE: The unit can only be rebooted when no transactions are taking place.

When someone is refuelling the C5000 unit can not be rebooted. The pumps may stop fuelling as the transaction has been interrupted.

Standard User Options

Users have access to all the following basic functionalities.

Transactions

Reference	Card Number	Local Date Time	Product	Product Code	Pump	Hose	Amount	Quantity
23	7824331000132...	02/03/2018 11:46:0...	Diesel		3	1	4.38	4.3
22	7824331000132...	02/03/2018 11:45:5...	Diesel		3	2	1.60	1.6
21	7824331000132...	02/03/2018 11:45:2...	Diesel		3	1	3.26	3.2
20	7824331000132...	02/03/2018 11:45:0...	Diesel		3	2	1.71	1.7
19	7824331000132...	02/03/2018 11:44:1...	Diesel		3	1	0.66	0.6
64	7824331000132...	23/02/2018 15:04:4...				2	2.84	2.8
63	7824331000132...	23/02/2018 13:46:3...				1	0.00	0.0
62	7824331000132...	23/02/2018 13:45:2...				1	7.26	7.2
61	7824331000132...	23/02/2018 13:43:4...				1	0.00	0.0
60	7824331000132...	23/02/2018 13:32:5...				2	2.60	2.6
59	7824331000132...	23/02/2018 13:31:5...				2	29.00	29.0
58	7824331000132...	23/02/2018 13:29:4...				1	12.10	12.1
57	7824331000132...	23/02/2018 13:28:4...				1	0.00	0.0

NOTE: Table columns shown on page can be expanded.

The Transactions storage is limited. When Transaction storage is at 100%, the user will have to Export CSV. This will reset the Transaction storage bar and cause the data to be stored in a separate place in the system. This allows more transactions to be recorded.

Ignore checksum Only load new transactions

NOTE: Select Refresh before adding more transactions.

Transactions that have not been exported will be viewed in the screen as default. To show exported transactions untick 'Only load new transactions'.

Tanks

The Tanks section indicates product details and volume of fuel in the tank.

Tanks

Tanks

Tank No.	Product	Produc...	Gross Volum...	Net Volume (L)	Safe Fill Level	Ullage	Water Height	Temperature
<								

Deliveries indicate when the last transaction occurred, including tank number and date time.

Deliveries (last 10)

Tank No.	Date Time	Gross			Net	
		Delivery (L)	Start (L)	End (L)	Delivery (L)	Start (L)

The data in this section can be downloaded by pressing Download. Select Refresh to view new data.

NOTE: A reboot is required for any changes to be applied.

Events

Events are notable events that occur with the pumps. The main event that should be examined is the Pump Snapshot event. This is an accumulative amount of fuel that has been pumped from the selected pump. Select Download to download the list of events on screen. Select Refresh to load the most recent events.

Events

Local D...	Event	Event...	Text	Pump	Hose	Unit Price	Amount	Quantity	Tank
2083-01-05...	Controller Pow...		80						
2083-01-05...	Pump Snapshot		46		1	1	1	0	0
2018-01-24...	Time update		76						
2018-01-24...	Controller Pow...		80						
2018-01-24...	Pump Snapshot		46		1	1	1	0	0
2018-01-24...	Time update		76						
2018-01-24...	Controller Pow...		80						
2018-01-24...	Time update		76						
2018-01-24...	Controller Pow...		80						
2018-01-24...	Time update		76						
2018-01-24...	Controller Pow...		80						
2018-01-24...	Time update		76						
2018-01-24...	Controller Pow...		80						
2018-01-24...	Time update		76						
2018-01-24...	Controller Pow...		80						
2018-01-24...	Time update		76						
2018-01-24...	Generic Event		70						
2018-01-24...	Generic Event		70						

Cards

In this section, a new card can be created with Create New card. Decide on a card number, PIN and owner details, then select Submit.

NOTE: Ensure Enabled box is ticked to validate card.

If a mistake has been made, select Edit and edit card details. Select the trash can icon if a card is not needed. The maximum Card storage is limited at 200 cards.

Cards

Cards

Card storage

9/200 cards in use

Card Number	Enabled	PIN	Card Total (I)	Owner detail 1	Owner detail 2	
12345	✗		0.0	123	456	Edit
123213	✗		0.0			Edit
123456	✓		0.0	123	456	Edit
245687f	✗		0.0	123	456	Edit
24568789	✓		0.0	123	456	Edit
1234567890123456...	✗		0.0			Edit
1234567890123456...	✗		0.0			Edit
ABCD1234	✗	1234	0.0	K	John	Edit
ERCD1234	✗	3333	0.0	G	Q	Edit

User IDs

User IDs consist of any 6 numbers or less. Select Edit to Edit User IDs and owner details. Tick the enable box to make the User ID valid for use. The trash can icon can be selected to permanently delete the user.

NOTE: A card can have multiple users.

Different users will have different User IDs. The purpose of this is to know which user has made a transaction, and ensure they are only fuelling when required.

NOTE: All files created **MUST** be a csv file not an excel file.

Import User IDs is another way of inserting new users. It may be easier for bulk user adding.

User IDs

User IDs

User ID storage

3/200 User IDs in use

User ID	Enabled	Owner detail		
1235	✗	Test	Edit	
12356	✗	Test	Edit	
54321	✓	test	Edit	

CompacOnsite Logins

For the security of the site, the standard passwords should be changed during set up of the unit. In case the passwords were not changed during installation, the process is outlined here. To change the passwords, go to CompacOnsite Logins, shown in the left options tab.

The screenshot shows a web interface titled "User Management". Below the title is a section labeled "Users" containing a table with three rows of user information. Each row has an "Edit" button next to it.

Username ▲		
tech	<i>Edit</i>	
admin	<i>Edit</i>	
user	<i>Edit</i>	

Not all users may be shown depending on the access level of the user. To edit, select Edit.

The screenshot shows the "Edit User" form. It has a header "Edit User" and two main sections: "Username:" and "Password". The "Username:" field contains the text "tech". The "Password" field is empty and has a note below it stating "Minimum of 8 characters". A "Submit" button is located at the bottom of the form.

Enter the desired new password, confirm this and press Submit.

Error Codes

Error codes will show on the litres display when common faults occur. Use the following table to diagnose these faults.

Error Code	Fault	Action
Er FL0	Excess flow	Maximum flow rate exceeded
Er r 8	Excess reverse flow	Check product is not flowing back into the tank once the delivery has finished
Er r 9	Pulse Meter Error	If the problem persists, repower the unit. Replace the meter if necessary.
Er 50	Meter Modbus error	Check that the meter is plugged in correctly. Check correct configuration and correct software installed
Er 52	Meter error	If the problem persists, repower the unit. Replace the meter if necessary
Er 53	Meter stopped vibrating	Replace meter
Er 54	Temperature sensor failure	Replace meter
Er 55	Meter not ready	Wait for meter to calibrate. If the problem persists, repower the unit
Abd	Display error	Check display cable for loose wires/crimps. Replace display PCB if necessary

Installation Checklist

When a new unit is being installed use the following checklist to make sure the unit is fully operational. Check each box or write N/A where not applicable.

Mechanical Checklist	
Check that the unit is securely mounted and does not shake	
Check that unit will not be exposed to harsh weather conditions	
Ensure the unit is connected properly	
Check that the unit is not damaged and all signage is visible	
Check that the K-Factor switch is properly sealed	
Thoroughly check the unit for leaks	
Ensure the covers are attached and secured	
Check that flow is correct	
Ensure the K-Factor has been calibrated	

Transaction Checklist	
Perform a test transaction with a valid PIN, card or HID (whichever is applicable)	
Check price and ensure correct amount of fuel is being dispensed	
Try to take fuel with an invalid PIN, card or HID and ensure it declines	
Lift the nozzle without entering a transaction and ensure no fuel is dispensed	

Electrical Checklist	
Ensure the motor(s) are running correctly	
Check that the incoming mains has been properly connected as shown in Electrical Installation	
Check that the dispenser contactor connections have been made as shown in Electrical Installation	

Software Checklist	
Check that the set up menu can be accessed from the unit with the passcode (Refer to Software Setup)	
Check that transactions are being recorded on CompacOnsite	
Check that when settings are changed from the unit, they are also changed on CompacOnsite (and vice versa)	
Check that the retailer understands how to use CompacOnsite to get transactions <i>NOTE: It is recommended to give the retailer User rights to prevent them changing the settings of the software.</i>	
Ensure that the CompacOnsite standard passwords have been changed	

Installation Checklist