

- · Use appropriate cable for hazardous zones where required
- It is recommended to use ferrules on all communication wires
- · Gland all cables that enter the cabinet
- Seal all unused holes in the cabinet
- External aerial cable (option) screws into RF socket on cellular modem
- Always replace electrical covers



OPT INSTALLATION WIRING DIAGRAM Gilbarco/Gilbarco Pump Connections

REVISION A

DATE: 29 August 2014